



## HOW DO I CLEAN & CARE FOR MY MY FIXTURE?

### LINISHED BRASS

All brass finishes are lacquered lightly to seal and prevent patinas. Dust gently with a duster or soft rag. Do not use commercial cleaners. A clean soft damp rag may also be used.

### POWDER COAT AND ELECTROPLATE FINISHES

Dust gently with a soft rag or duster. Do not use abrasives. A clean soft damp rag may also be used.

### GLASS

For clear glass and coloured glass, wipe gently with a soft, clean cloth moistened with warm water; 'Isocol' rubbing alcohol may alternatively be used.

For frosted or etched glass, dust gently with a duster or soft rag. Do not scrub frosted glass. Removable shades can be washed carefully in warm to hot water in the sink with minimal cleaning solution.

Ensure lights are turned off prior to cleaning or maintenance.

### PORCELAIN

For porcelain shades, use a soft rag with diluted clear or white cleaning solution, or dust gently with a duster or soft rag.

### LEATHER

Dust gently with a soft rag or duster. Do not use commercial cleaning agents.

### PAPER

For paper shades, dust gently with a duster or soft cloth. Take care not to place pressure on the paper shade